


SAVE THESE INSTRUCTIONS



Create a drip loop

1. To avoid the possibility of the appliance plug or outlet getting wet, position plug or outlet getting wet, position aquarium stand and tank to one side of wall-mounted outlet to prevent water from dripping onto the outlet or plug. A drip loop, shown in the figure above, should be arranged by the user for each cord connecting an aquarium appliance to an outlet. The drip loop is that part of the cord below the level of the outlet or the connector to prevent water from traveling along the cord and coming in contact with the outlet.

- A. If the appliance shows any sign of abnormal water leakage, immediately unplug it from the power source.
 - B. Carefully examine the aquarium heater after installation. It should not be plugged in if there is water on parts not intended to be wet.
 - C. Do not operate any appliance if it has a damaged cord or plug, if it is malfunctioning or has been dropped or damaged in any manner.
- DANGER:** To avoid possible electric shock, special care should be taken since water is employed in the used of aquariums. For each of the following situations, do not attempt repairs by yourself, return the appliance to an authorized service facility for service, or discard the appliance.

READ AND FOLLOW ALL SAFETY INSTRUCTIONS AND NOTICES ON THE APPLIANCE

2. If the plug or outlet does get wet, DO NOT unplug the cord. Disconnect the fuse or circuit breaker that supplies power to the appliance. Then unplug and examine for presence of water in the outlet. If an extension cord is necessary, a cord with the proper rating should be used. A cord rated for less amperes or watts than the appliance rating may overheat. Care should be taken to arrange the cord so that it will not be tripped over or pulled.
4. Close supervision is necessary when any appliance is used by or near children.
5. To avoid injury, do not touch moving parts or hot parts such as heaters, reflectors, lamp bulbs or the like.
6. Always unplug an appliance from an outlet when not in use, before putting on or taking off parts and before cleaning. Never yank the cord to pull the plug from the outlet. Grasp the plug and pull to disconnect.
7. Do not use an appliance for other than the intended use. The use of attachments not recommended or sold by the appliance manufacturer may cause an unsafe condition.
8. Do not install or store the appliance where it will be exposed to the weather or to temperatures below freezing.
9. Make sure an appliance mounted on a tank is securely installed before operating it.
10. This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not attempt to defeat this safety feature.

IMPORTANT SAFEGUARDS



Interpet has applied over 60 years of aquatic experience to ensure every element of the design of this product has been carefully considered to help you enjoy aquarium keeping.

☎ 844-660-FISH (3474)

Interpet Ltd. Vincent Lane, Dorking, Surrey
RH4 3YX, England, UK

www.interpetlife.com

Version 0001



LIFE THERMAL Submersible Aquarium Heater



IMPORTANT SAFETY INSTRUCTIONS

SAVE THESE INSTRUCTIONS FOR FUTURE USE

INSTALLATION

Designed for efficient, reliable and safe heat output. Due to its waterproof design, this heater can be completely submersed in both fresh and saltwater.

Before plugging the appliance into the electrical power source, the user is to install the appliance safely.

Check to ensure the heater is the correct size to maintain the temperature in the size of the aquarium you own (see Fig 1).

FIG 1

Watts	Aquarium Gallons
50	3-10
100	10-20
150	20-30
200	30-50

FIG 2



SET TEMPERATURE

The heater is preset at 75°F (24°C). If you need a different aquarium temperature turn the control knob (see Fig 2) clockwise to increase temperature and anti-clockwise to reduce temperature until the indicator is adjacent to the desired temperature.

POSITION IN AQUARIUM

Use suckers positioned as indicated (do not place over the heating element) to attach heater to inside of aquarium.

Place at an angle of 45 degrees (see Fig 3) for best effect or in an area of good water flow, see maximum/minimum depth (Fig 4).

Turn on heater, the indicator light will come on and stay on until the heater reaches the set temperature.

FIG 3





FIG 4



MAINTENANCE

- Unplug or switch off all appliances in the aquarium before carrying out maintenance.
- Do not use detergents or other chemical cleaners.
- To clean the heater, unplug and remove it from the aquarium. Wash the heater with clean water.
- When reinstalling the heater, select your desired location and position the heater below the minimum water level.
- This appliance has no user serviceable parts.
- For indoor use only, not to be used in a bathroom.

TROUBLESHOOTING

If the heater has been working for more than 24 hours and the water temperature is more or less than 2 degrees of the set temperature, check that:

1. The thermometer reading is accurate
2. The power has been switched on
3. The temperature has been set correctly
4. The water surface is above the water level mark
5. The heater is correct for the aquarium size

WARRANTY

Interpet limited warrants this product against defects in materials or workmanship for a period of 5 years from the date of original purchase. The warranty covers only any defects caused during normal use and operation of the Life Thermal Submersible Aquarium Heater, in accordance with the instructions enclosed.

If the product exhibits such a defect, Interpet limited will repair or replace it without cost for parts or labour. The product must be shipped post-paid to Interpet Limited. Proof of purchase is required. This warranty does not apply to problems or damage caused by unauthorised modifications, misuse, improper or inadequate maintenance, accidents, or operations outside the product instructions or specifications.

All implied warranties, including any implied warranty of merchantability or fitness for any purpose, are limited to 12 months from date of original purchase.

The warranty service includes repair or replacement of the Life Thermal Submersible Aquarium Heater at Interpet Limited discretion. In no event shall Interpet or the manufacturer be liable for any direct, indirect, special, incidental or consequential damages, including loss of livestock, arising from a defect in this product.

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation may not apply to you if you purchased the product in one of those states. This warranty provides specific legal rights. You may have other legal rights that vary from state to state.

Questions or need spare parts, please visit www.interpetlife.com.

Consumer Advice contact details

☎ 844-660-FISH(3474)

Interpet Ltd. Vincent Lane, Dorking, Surrey, RH4 3YX, UK

www.interpetlife.com